

Curre guidelines and instructions

Model: C19001

Order

- Frame Model code/color
- Temple length
- Quantity
- Temple tip to fix to frame (Yes/No)

Temple Length	Temple Tip Model	Hole depth
136 mm	TT113075L (left) TT113075R (right)	65 mm
138 mm	TT113077L (left) TT113077R (right)	70 mm
141 mm	TT113080L (left) TT113080R (right)	70 mm
146 mm	TT113085L (left) TT113085R (right)	70 mm
151 mm	TT113090L (left) TT113090R (right)	70 mm

Price

Extra Temple Tip Wholesale Price: SGD 40 nett.

Recommended Retail Price: SGD 60

Fitting Instructions:

1. Insert temple tip over the metal wire until it cannot go in any further.
2. If the temple tip does not fully cover the metal wire, heat the temple tip for a minute and push the temple tip in while it is still warm.
3. For curre temple length 136 mm, cut off approximately 5 to 10 mm of the metal wire.
4. For all other temple length, if the temple tip does not fully cover the metal wire, cut off a short segment of the metal wire.

Contact Information

Email: sales@betasimplicity.com

WhatsApp: +65 8846 3387